Power supply
Signal input
Signal output
GND

Indicate: efi cable components used in the wire line and the main cable wire, although part color is the same, but not between conduction, the only connection is that two eight hole plastic parts

Voltage regulator rectifier
12V 30Ah
Start the relay
Start the motor
Hoist control switch
Hoist the controller
Hoist motor
Ignition switch components
The main relay combination
Fan controller
Fan motor
Frame by iron
Flasher unit
Brake switch
The horn
Package with the main beam, cannot be replaced
The RC socket combination
Drive switch
The rear axle electromagnetic valve controller
Rear axle solenoid valve
Front axle electromagnetic coil
Fuel pump parts
Parking switch
Relay combination
Black connector combination instrument
Combination instrument gray connector
Speed Sensor
Documents elbow combination
Safety belt lock combination
Combination instrument parts
The left front combination
The right front combination
The left front turn signals
The right front turn signals
Left after a lamp combination
License plate lamp after combination
Right rear combination lamp
ECU interface (ZJ, Black)
ECU interface (ZJ, Gray)

0.5mm²----0.05
1.25mm²----0.15
2.0mm²----2.0
3.0mm²----3.0
8.0mm²----4.0
14mm²----7.0

HS800UTV