



STATORS READINGS

Stator type= 3 phase

Pick up coil reading = 122 Ohms

Reading Between phases = .4-.5 Ohms

AC voltage at idle = 15V-17V

Nothing going from phases to ground