




ELECTRIC STARTING SYSTEM CIRCUIT DIAGRAM



LIGHTING SYSTEM CIRCUIT DIAGRAM



SIGNALING SYSTEM CIRCUIT DIAGRAM



- 1, Battery parts
- 6, Ignition switch parts
- 12, Brake switch
- 17, Flasher
- 18, Emergency lamp switch
- 19, Turn light convert switch
- 20, Front turn signal light assy. (L)
- 21, Front turn signal light assy. (R)
- 26, Rear brake light assy. (L)
- 27, Rear turn signal light assy. (L)
- 28, Rear brake light assy. (R)
- 29, Rear turn signal light assy. (R)
- 30, Rear registration plate lamp assy.
- 31, The speed sensor parts
- 32, Buzzer
- 38, Documents show assy.
- 47, Safety belt lock catch switch
- 48, Parking final motion switch
- 49, Fuel pump parts
- 50, Oil pressure sensor
- 51, Water temperature sensor

2WD/4WD SELECTING SYSTEM CIRCUIT DIAGRAM

